



## Orgasol<sup>®</sup> 4000 EXD NAT COS CARESSE

## COOL DOWN TRANSFORMING HOT-POURED EMULSION

Want to recover after your workout session ? Cool Down is a cooling gel moisturizer that instantly refreshes hydrates and comfort your face.

It looks like fresh snow, with a fun crunchy feel under the fingers. It releases a blissful dew upon application – the wax is seemingly magically absorbed and leaves a sensation of freshness and lightness.

The quick break effect, fast absorption and the smooth powdery after feel are delivered by Orgasol® 4000 EXD NAT COS CARESSE.

## Formulation ARK 20-002

| Phase | Ingredients (INCI Name)  | %     |
|-------|--|-------|
| Al    | CYCLOPENTASILOXANE (AND) DIMETHICONE (AND) DIMETHICONE/<br>VINYL DIMETHICONE CROSSPOLYMER (AND) PEG-10 DIMETHICONE | 4.00  |
| Al    | DICAPRYLYL CARBONATE (AND) TOCOPHEROL  | 2.00  |
| Al    | STEARYL HEPTANOATE (AND) STEARYL CAPRYLATE   | 3.50  |
| Al    | OZOKERITE  | 3.00  |
| A2    | CYCLOPENTASILOXANE   | 5.00  |
| В     | AQUA (WATER)   | 73.00 |
| В     | SODIUM CHLORIDE  | 0.50  |
| В     | GLYCERIN   | 3.00  |
| В     | PROPANEDIOL  | 2.00  |
| В     | AQUA (WATER) (AND) SODIUM BENZOATE (AND) POTASSIUM SOR-<br>BATE  | 0.50  |
| B2    | CITRIC ACID (10% AQUEOUS SOLUTION)   | 0.11  |
| С     | ORGASOL® 4000 EXD NAT COS CARESSE: NYLON- 6/12   | 3.00  |

## Procedure :

- Weigh phase A and heat the mix at 80°C.
- Introduce A2 into A just before emulsion.
- In a second vessel, heat phase B at 80°C.
- Add B2 to phase B.
- Emulsion at 75-80°C: In 1 minute introduce phase B into phase A under low to moderate stirring.
- Then add C during another minute under moderate stirring.
- Pour immediately around 70°C.



orgasolcosmetics.com info.orgasol@arkema.com